


1 Find Mounting Location

Mount device horizontally with the label side up, without any metal obstructions.

- No Metal obstructions
- Mount as high in the dash as possible
- Mount at least 12 inches away from the radio and speakers.
- DO NOT SECURE THE DEVICE**




2 F-TRK Device Connections

- The 3 wire install connections are mandatory. The device will not operate without these connections.
- The T2C Yellow, Green and Brown wires are outputs. When connected using a relay, can drive optional features.
- The T2C Orange and Blue wires are inputs. When connected using a relay, can drive optional features.

Basic Fleet Tracking/Optional Features


**All Connections
Must Be Soldered
DO NOT USE CLIPS**



3 Check Signal

- Confirm green GPS lock & amber cellular network lights are solid
- Vehicle must be outdoors to activate GPS signal

Note: Cellular & GPS Lock may take up to several hours



4 Test

- Log In to your dealer account
- Enter the device ESN
- Test all installed features
- Assure red/green timer is displaying on "start" bar to confirm true ignition connection

5 Secure Device

- Secure the device to the chosen mounting location using double sided tape or tie wires.
- White label side up

+1 306.979.8900 | About Us | Media Buzz | Blog

CUSTOMER LOGIN

DEALER LOGIN

No Dealer Account?

Create one at www.Text2Car.com
Or, call the head office and have technical support test all installed features

TEXT2CAR.COM

306.979.8900

info@text2car.com

